




Bring the simplicity of Playaway all-in-one audiobooks to life for your staff and patrons with this how-to guide.



**\*To Turn Off:** Hold down  for 3 seconds.

**To Lock + Unlock Keypad:** While in PLAY, quickly click power once;  or  symbol will appear on LCD screen.

**\*\*Backlit LCD Screen**



- ① Current Function (Play/Pause/Lock)
- ② Current • Total (Chapters)
- ③ Battery Life
- ④ Time Remaining in Chapter
- ⑤ Book Progress Bar

## start listening



Plug earphones, speakers, or car adapter into the universal headphone jack on bottom of unit.



Press the POWER button.\*



Press the PLAY button.

**Enjoy your HD audiobook experience!**

\*Hint: If the power does not turn on, you may need to insert or replace the AAA battery.